

Magnetic Lock (500kg)



Specification

Model	Size(mm)	Voltage	Current	Holding Force	Lock Signal	Door Signal	Time	Door
YM-500N	265Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10% 24V/250mA±10%	500kg(1200Lbs)	No	No	No	Single Door
YM-500N(LED)	265Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10% 24V/250mA±10%	500kg(1200Lbs)	NO/NC/COM	No	No	Single Door
YM-500NT(LED)	265Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10% 24V/250mA±10%	500kg(1200Lbs)	NO/NC/COM	No	0/3/6/9sec.	Single Door
YM-500N(LED)-DS	265Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10% 24V/250mA±10%	500kg(1200Lbs)	NO/NC/COM	NO/NC/COM	No	Single Door
YM-500ND	530Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10%x2 24V/250mA±10%x2	500kgx2(1200Lbsx2)	No	No	No	Double Door
YM-500ND(LED)	530Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10%x2 24V/250mA±10%x2	500kgx2(1200Lbsx2)	NO/NC/COM	No	No	Double Door
YM-500NTD(LED)	530Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10%x2 24V/250mA±10%x2	500kgx2(1200Lbsx2)	NO/NC/COM	No	0/3/6/9sec.	Double Door
YM-500ND(LED)-DS	530Lx73Wx41H	DC12V(Default); DC24V(Order)	12V/500mA±10%x2 24V/250mA±10%x2	500kgx2(1200Lbsx2)	NO/NC/COM	NO/NC/COM	No	Double Door

Diagram(unit:mm)



Installation





Fold the plate to 90 $^\circ\,$.





Drill holes based on the marked positions.



Place the rubber ring between armature plate and door leaf.



Close the door to test holding force. The angle between armature plate and magnetic lock can be adjusted by adding or reducing washers.



Inside:Drill a hole diameter is 8mm folding the plastic straight pin





Use Allen key to remove the mounting plate from lock body.



After all the appropriate procedures, the holding force can be maximized. Finally, fix the tamper screw.



Close the door first, then place the upper side of template on door frame, while adjust the left side next to the door leaf.



Strike the pin into the armature plate slightly (to avoid movement).



Fix the mounting plate on the door frame according to the holes drilled earlier.



Drill a hole Inside: Diameter is 8mm Outside: Diameter is16mm



Mark screw positions of armature plate and magnetic lock on door leaf and door frame respectively.



Make a combination based on the picture(add washer accordingly). The rubber ring must be added.



Use Allen key to screw the lock body on the mounting plate.



Drill a hole Inside: Diameter is 8mm Outside: Diameter is 12.7mm

Notice: Thickness of Door Leaf: 350LBS: 44mm 600LBS: 50mm 800LBS: 48mm 1200LBS: 46mm

A. The screw of armature plate should not be fixed too tight. Proper elasticity should be guaranteed for the rubber ring so that the armature plate can adjust itself to the appropriate position. B. Check the jumper's position before connecting. Figure out it represents 12VDC or 24VDC.

Bracket Installation

Different brackets are available according to different types of doors. For example, narrow door, frameless glass door and inward opening door.



www.yli.cn

Circuit Board Diagram

A.12VDC Input:

Connect the positive(+)lead from a 12VDC power source to V +.

Connect the ground(-)lead from a 12VDC power source to V -.

Check jumper for 12 VDC operation.

Wiring Instruction of Single Door Magnetic Lock



No signal output from YM-500N

B.24VDC Input: Connect the positive(+)lead from a 24VDC power source to V +. Connect the ground(-)lead from a 24VDC power source to V -. Check jumper for 24 VDC operation.



Model with DS will come with one more set of signal for door sensor and lock status(NO/NC/COM contact)

	ON 1 2 0S	ON 1 2 3S	^{ON} 1 2 6S	9S	
--	-----------------	-----------------	----------------------------	----	--

Model with T will come with this function

Wiring Instruction of Double Door Magnetic Lock

Connection: green wire or white plug, except the models without LED indicator and signal output; only when it detects that double doors have been locked, there will be normal signal output.



Wire Connection

